


Parts List:

- | | |
|--------------------|------------------|
| 1) Red Lever | 5) Roof Tray |
| 2) Glide Bar | 6) Bent Arm |
| 3) Roof Rack Clamp | 7) Carriage Bolt |
| 4) Barrel Nut | 8) 19" Strap |



In The Box:

STANDARD MOUNT

- 1UP USA Roof Rack
- 1 Silver Roof Rack Wrench
- 4 Barrel Nuts
- 4 Carriage Bolts
- 4 Black Washers
- 4 Silver Washers
- 2 Roof Rack Clamps

OPTIONAL FLUSH MOUNT


- 1UP USA Roof Rack
- 1 Yellow Allen Wrench
- 2 Carriage Bolts
- 2 Jam Nuts
- 4 Flat Head Screws
- 4 Yellow Tee Nuts
- 2 Roof Rack Clamps

Product Notes:

- Fits 16"-29" wheels, up to 3.1" wide. For wider tires, use a Fat Bike Spacer Kit, (sold separately).
- Rated to hold a bike up to 50 lbs.

Step 1:


- Slide all four Carriage Bolts into bottom slot of Roof Tray.
- Position Carriage Bolts so they sit evenly spaced on vehicles' cross bars.



Step 2:

- Insert provided Barrel Nuts into the holes of the Roof Rack Clamp and position Roof Rack Clamps underneath crossbars.
- Connect the Barrel Nuts and Carriage bolts, tightening by hand and then with Silver Security Wrench.
 - Periodically check tightness of Barrel Nuts

Note: The Black and Silver Washers are for minimum adjustments in length if needed.




Optional Flush Mount

Step 1:

- Slide two Carriage Bolts into bottom slot of Roof Tray.
- Position the Roof Rack Clamp perpendicular to the tray and use installed carriage bolt and jam nut to tighten clamp in place. Repeat for second clamp.


Note: Position Roof Rack Clamps to accommodate existing crossbars.



Step 2:

- Position two yellow Tee Nuts into the crossbar allowing each hole on the Roof Rack Clamp to align with its corresponding Tee Nut.
- Install the Flat Head Screw through the clamp and tightened into Tee Nut. Use supplied Allen Wrench to clamp firm.


Note: The Black and Silver Washers are for minimum adjustments in length if needed.



Loading Bikes

- Lift the Red Lever up parallel with the Glide Bar while pulling up on the Bent Arm. Do this on both the driver and passenger side.

Note: Do not move the Bent Arms up without lifting the Red Lever.



- Set bike on trays in desired position.
- Pivot Bent Arms down to tire firmly.

Note: When loading multiple bikes stagger them to avoid seat and handlebar interference.




Unloading Bikes


- Compress bent arm/spools into tire slightly while lifting up on the Red Lever. This relieves pressure and allows the red lever to easily unlock.
- Pivot Bent arms from bike to unload.

Wheel Settings

- The Rack is set to hold 26", 27.5", 29", or 700-C wheels. If bike tires are smaller, see instructions below to adjust spools accordingly.



- With a ½" wrench, remove the hex nut and washer.
- Slide the bolt out of the spools and re-assemble the spools in the desired wheel position, firmly tightening the hex nut.



Additional Instructions

- Wipe salt off of the nuts and bolts with a damp cloth to prevent corrosion.
- Check and retighten any hardware on the rack periodically to ensure proper working conditions.

Questions or comments? Contact our support team via email at email@1up-usa.com